



NOTES

- (1) Socket to be Underwriters Laboratory (UL) listed.
- (2) Socket shall be 20A class only.
- (3) Meter shall be 4' - 5' 6" from finished grade.
- (4) Socket shall have two separate covers for meter and test switch compartments.
- (5) Latching bottom compartment shall lock both covers.
- (6) Metering and instrument cabinets shall not be used to house Customer-owned equipment, such as distribution panels or other equipment, nor used as a junction box/trough for the distribution of circuits.
- (7) Customer building numbers must be permanently painted on proper meter panels.
- (8) PNM does not permit a trough ahead of meter socket.

| Approved Equipment | | |
|--------------------|-------------------------|--------------|
| Manufacturer | Item | Mfg Part # |
| Milbank | 20A 13T Ringless Socket | UC3423-XL |
| Milbank | 20A 13T Ringless Socket | UC3445-XL-13 |
| Milbank | 20A 13T Ringless Socket | UC3445-XL |
| Siemens | 20A 13T Ringless Socket | 9837-8501 |
| Siemens | 20A 13T Ringless Socket | 9837-8502 |
| Siemens | 20A 13T Ringless Socket | 9837-8503 |
| Siemens | 20A 13T Ringless Socket | 9837-8543 |

For ease of checking service without interruption, PNM will no longer allow ring meter sockets as of 12/01/2013.