



NOTES

- (1) Bond neutral bus, cabinet and meter bases to common ground.
- (2) Bond CT secondary meter frames to cabinet and neutral bus.
- (3) 1" placards to be used under main disconnect and adjacent to the corresponding socket on a non-removable part of the cabinet. No painted or written identification will be accepted.
- (4) If conductor are used instead of bus, they must be kept behind meter board.
- (5) Load conductors must leave switchgear through bottom area. NEC does not allow load conductors to exit through line bus area.

REFERENCES

- (1) See DM-4-11.0 Maximum Available Fault currents
- (2) See DS-7-16.10 Guard post
- (3) See MS-4-6.0 120/208-277/480V Switchgear
- (4) See EUSERC Section 300 Metering and Service Equipment